

Stainless Steel Furniture Care

Stainless steel outdoor furniture requires regular maintenance to keep it looking new, and should be cleaned routinely. Always use a non-abrasive cloth and water with or without a gentle detergent. To maintain a streak free finish, always wipe with the directional grain of the steel, not across it. After washing, rinse with fresh water and dry thoroughly.

For finger prints or smudges, you may wish to use a stainless steel cleaner. Always read the manufacturer's instructions carefully before applying a stainless steel cleaning product. If more aggressive cleaning is required, the type of contaminant needs to be determined and an appropriate cleaner chosen that is safe for stainless steel.

Do not use bleach, cleaners containing chlorine, or abrasive cleaners on stainless steel. Steel wool pads or highly abrasive cloths shouldn't be used. Some of the fine particles can lodge in the surface of the stainless and will eventually rust, giving the appearance that the stainless itself is rusting.

Should you have any additional questions, please don't hesitate to call the showroom. We are always happy to help.